

Notice

When using the wheelspacers you have to verify that the wheels being used have suitable cut-outs to take up the original bolts. Without these cut-outs it is not possible to use the wheels or wheelspacers. Please check as follows:
Stud length (e.g. 25 mm) - spacer thickness (e.g. 15 mm) = 10 mm excess length. So the cut-out should have 11 mm depth to take the original stud.
Further the cut-out should have min. 22 mm x 22 mm height/width to take the overlapping nut.